



Syncro ring in correct window

The index tab on the syncro ring MUST be installed against the pressure block in the shift hub (see photo). Failure to install the syncro ring correctly will cause grinding and require gearbox disassembly to correct.